


### (1) NAME OF COMPONENTS





### (2) SAFETY PRECAUTIONS: Before use, read the following safety precautions

Please read this instruction manual thoroughly in order to use this new pocket size D.M.M. safely.

And for reference, please keep this manual together with the meter.

Instructions followed the sign " \(\frac{\text{\Lambda}}{\text{WARNING}}\)" must be obeyed to avoid accidental burn or electric

### :Very important instruction for safe use.

- The warning messages are intended to prevent accidents to operating personnel
- such as burn and electric shock.

  The caution messages are intended to prevent damage to the instrument.

## — 🕂 WARNING —

## ■To avoid damage to instrument or electrical

The maximum input voltage level depend on the over-voltage categories specified by the safety standards.

These categories are described as below to protect operators against transient impulse voltages in power lines.

Over-Voltage Category(CAT.)	Maximum Input Voltage
I	600V
II	300V

Over-voltage category I (CAT. I): Covers the path from a main outlet, through a

## power transformer, to a circuit in the transformer's

## Over-voltage category II (CAT. II):

Covers a primary-stage circuit of equipment connected to a main outlet.

⑤ The D. M. M. now shows the measured value

that it retains.

⑤ You can repeat steps ② to ⑤ as many times as you like as long as the display shows the

symbol.

To cancel this function, press the A-HOLD

Do not mistake the following for a malfunction!

In DC voltage measurement, the Auto Hold function is only available for range over 4V.

• In a capacitor check, the Auto Hold function

• The Auto Hold function cannot be applied to

requires few seconds before it takes effect.

unstable signals.

## 2-2 Warning Instruction for Safe Use

## **△ WARNING**

To make sure that the meter is used safely, the owner has to follow the instructions while using

- 1. Pay special attention when measuring the voltage of AC 30Vrms or DC 60V or more to

O How to store test leads.

- them, the ground lead must be disconnected 7. Always keep your fingers behind the finger
- measurement.
  8. Be sure to disconnect the test pins from the

circuit when changing the function

- avoid injury.

  2. Never apply an input signals exceeding the
- maximum rating input value.

  3. Never use meter for measuring the line connected with equipment (i.e. motors) that generates induced or surge voltage since it may exceed the maximum allowable voltage.

  4. Never use meter if the meter or test leads
- are damaged or broken.

  5. Never use uncased meter.

  6. When connecting the test leads, first connect the ground lead (black). When disconnecting
- guards on the probe when making

9. Before starting measurement, make sure that the function is properly set in accordance with the measurement.

10. Never use meter with wet hands or in a

damp environment.

1. Never open tester case except when

replacing batteries. Do not attempt any alteration of original specifications.

### 2-3 Maximum Overload Protection Input

Function	Input terminal	Maximum rating input value	Maximum overload Protection input
V (DCV)		DC 600V	DC 600V
¥ (ACV)	(Red)	AC 600V	AC 600V rms
Ω·•·I)· <b>→</b>	(Black)	⚠Voltage and current input prohibited	AC 000V IIIIS

Note: AC voltage is regulated by rms value of sinusoidal wave

### (3) DESCRIPTION OF FUNCTIONS

- Power Switch and Function Switch Turn the switch for power on and off and to select the functions of DCV,  $ACV, \Omega, \bullet \bullet \bullet 1$ ,  $\bullet \bullet \bullet$
- Battery Voltage Drop Indication Display If the internal battery has been consumed and the voltage drops, the display shows ... In this case, replace with 2 new batteries. (LR-

## Select Function

Press SELECT when the following functions are selected: Ω/••1 :Select for Measuring Capacitance or Checking Continuity.

Auto Hold Function

© Press A-HOLD key. (The display shows the A-B symbol.)

© Connect the test leads to the object under 3 When the reading stabilizes, the buzzer sounds.

Remove the testing leads from the object

### (4) MEASUREMENT PROCEDURE


### 4-1 Voltage Measurement

- space first of all.

  ②Red-black lead wire of the test leads is pulled toward a display and it folds in two and a folded place is put inside the upper part of store space.


  3An end of lead wire is accepted inside the
- lower part of store space.

①Test rod of red-black test leads is let in to store




- 1. Never apply an input signals exceeding the maximum rating input value.

  2. Be sure to disconnect the test pins from the
  - circuit when changing the function.
    3. Always keep your fingers behind the finger guards on the probe when making
  - 4-1-1 V (DCV) Measurement Maximum Rating Input Value 600V DC (CAT. I)
  - Applications.
     Measure D.C. circuits.
  - 2) Measuring Ranges 5 ranges from 400mV to 600V.



## 3) Measurement Procedure

- ③ Read the value on the display.
  ④ After measurement, remove the red and black test pins from the circuit measured.
- The display fluctuates when the test leads are
- removed. This is not malfunction
- 4-1-2 ♥ (ACV) Measurement Maximum Rating Input Value 600V AC (CAT. I) 1) Applications.
- Measure sine-wave A.C. voltages such as lighting
- 2) Measuring Ranges 4 ranges from 4V to 600V.



3) Measurement Procedure
① Set the function switch at ∠ (ACV) range.
② Apply the red and black test pins to the circuit

the display of waveforms other than sine waves. • The accuracy guaranteed frequency range is 45 Hz to 400Hz.

### 4-2 Resistance Measurement

— <u></u> WARNING Never apply voltage to the input terminals.

- 1) Applications
- Resistance of resistors and circuits is measured.
- 2) Measuring Ranges 6 ranges from 400  $\Omega$  to 40M  $\!\Omega$  .
- ) Measurement Procedure  $\bigcirc$  Set the function switch at  $\Omega$  (Press SELECT
- key until  $\Omega$  is shown on display). ② Apply the red and black test pins to an object
- to measure.

  ③ Read the value on the display.

  ④ After measurement, release the red and black test pins from the object measured.

3 For a short-circuited diode, a value near 0mV

- If measurement is likely to be influenced by noise, shield the object to measure with negative potential (

  test lead black).
- If a test pin is touched by a finger during measurement, measurement will be influenced by the resistance in the human body to result in

## 4-3 \*\*\*) Checking Continuity


### - ∕N WARNING

Never apply voltage to the input terminals.

- Checking the continuity of wiring and selecting 2) How to Use
  ① Set the function switch at •••) (Press SELECT
- key until •1) is shown on display). ② Apply the red and black test pins to a circuit or
- conductor to measure.

  ③ The continuity can be judged by whether the

- ⓐ The continuity can be judged by whether the buzzer sounds or not.
  ④ After measurement, release the red and black test pins from the object measured.
   The buzzer sounds when the resistance in a circuit to measure is less than about 70Ω.



## 4-4 Testing Diode


### **.** MARNING → Never apply voltage to the input terminals.

- The quality of diodes tested.
- 2) How to Use
  ① Set the function switch at → range.
  ② Connect the test leads to the diode to be tested. As shown in Fig. (A), when measuring
- the forward voltage across diode, a normal diode will indicate 0.5 to 0.7V (GE Doide 0.2V~0.3V), and as shown in Fig. (B) the reverse voltage will indicate "OL" (same as an open condition).

The button cell is made of oxidized silver, etc. Please keep it away from little children lest they should swallow it in.

Set a battery with its polarities facing in the

 $-\underline{\bigwedge}$  Caution -



## ①The D. M. M. will power off automatically in 20 minutes later after the last operation was

- stopped.
  ②The alarm buzzer sounds 7 times before around 1 minute of power off.

  ③Press any key or turn the switch can postpone the power-off time or restart the D. M.M. is turned off.

  ④To cancel the Auto Power Off Function, hold
- down the SELECT key and then set the function switch from OFF to the position of any desired measurement mode. (The AUTO POWER OFF indication turns off when the


## (6) MAINTENANCE

- 6-1 Battery Replacement - ∱ WARNING 1. If the rear case or the battery lid is removed
- with input applied to the input terminals, you may get electric shock. Before starting the applied.

  2. Before starting the work, be sure to turn OFF
- (How to Replace)
  ①Remove the battery lid screw with a
- screwdriver.

  ②Remove the battery cover. Take out the batteries and replace with 2 new

batteries.Attach the battery lid and screw it on.



# 1. For cleaning, use dry soft cloth and wipe it

correct directions.

6-2 Storage

- lightly.

  2. The panel and the case are not resistant to Ine panel and the case are not resistant to heat. Do not place the instrument near heat-generating devices (such as a soldering iron).
   Do not store the instrument in a place which it may be subjected to vibration or which it may fall.
   For storing the instrument, avoid hot, cold or humid places or places under direct subject.
- humid places or places under direct sunlight or where condensation is anticipated.

Following the above instructions, store the instrument in good environment. (See 7-1)

### (7) SPECIFICATIONS 7-1 General Specifications

Polarity

: Dual integration mode Measuring method : Counter approx. 4300 counts max.

: Auto range : "OL" mark. (Voltage only) Over indication "---" mark. (Others)
: Automatic selection ("-" is displayed

Low hattery indication : If the internal hattery has been consumed and the voltage the display shows :Approx. 2 times/sec. Sampling rate Operating temperature/humidity :0~50°C <80% RH. No condensation

:LR-44x2 or SR-44x2 Power supply Dimension & weight : 117(L)x76(W)x18(H)mm. Approx. 110g

Storage temperature/ :-10~60°C <70%RH. No condensation

:Instruction Manual ..... LR-44 Button Cell (installed) 2

### 8-2 Measurement Range and Accuracy Accuracy assurance range: 18~28°C <80% RH. CAT I 600V. CAT II 300V.


FUNCTION	DUNCE	RESOLUTION	ACCURACY	INPUT	MAXIMUM
	PONINGE		ACCOLACT	RESISTANCE	INPUT VOLTAGE
	400mV	0.1mV	1.21% + 2	>100MΩ	
	4V	0.001V	0.7% + 1	11MΩ	1
DCV	40V	0.01V	1.2% + 1		600V
	400V	0.1V		10MΩ	
	600V	1V			
	I			e detection and m	ns-value calibration
FUNCTION	RANGE	RESOLUTION	Mean-valu ACCURACY	INPUT	MAXIMUM
FUNCTION	RANGE 4V	RESOLUTION 0.001V		INPUT	MAXIMUM
			ACCURACY	INPUT RESISTANCE	MAXIMUM INPUT VOLTAGE
FUNCTION	4V	0.001V		INPUT RESISTANCE	MAXIMUM

This range may produce readout error equivalent to several times their resolutions

ACV	400V	0.1V	2% + 5		10MΩ,<50pF	600V rms
	600V	1V				
FUNCTION	RANGE	RESOLUTION	ACCURACY	MEASURING CURRENT	OPEN-LOOP VOLTAGE	MAXIMUM INPUT VOLTAGE
Ω	400Ω	0.1Ω	1.2% + 2	<1mA	<3.4V	
	4KΩ	0.001KΩ		<0.5mA	<1.0V	
	40KΩ	0.01KΩ		<70uA		600V
	400KΩ	0.1ΚΩ		<7uA	<0.7V	00074
	4MΩ	0.001MΩ	21% + 3	<0.7uA	NO.7V	
	40M0	0.04M0	5% ± 3	<70na		

## FUNCTION RANGE RESOLUTION ACCURACY FUNCTION MANSE RESOLUTION ACCURACY VOLTAGE INPUT VOLTAGE ••) 4/002 0.10 The fluzzer turns on for resistance former flux for the state of the state OPEN-CIRCUIT MAYIMUM | FUNCTION | RANGE | RESOLUTION | ACCURACY | OPEN-CIRCUIT | MAXIMUM | VOLTAGE | INPUT VOLTAGE | NPUT VOLTAGE | Smaller than 1.0mA) | 43.4V | 6000 | Control | Control

Specifications and external appearance of the product described above may be revised for modification without prior notice.



service@kingtony.com www.kingtony.com 8909DM1381KT 297x315mm